

Arranques en Caja Termoplástica

Arranque Directo Monofásico DLWM (Caja termoplástica)

Código	Referencia	Potencia (cv)	Tamaño Caja
10074640	DLWM-7D23P-RM06	0,25 - 0,33	2
10046432	DLWM-7D23P-RM08	0,5	2
13339096	DLWM-B9D23P-RM62	0,75 - 1,0	4
13339091	DLWM-B12D23P-RM64	1,5 - 2,0	4
13339093	DLWM-B18D23P-RM65	3	4
14212932	DLWM-B25D23P-RM67	4	4



Dimensiones DLWM

Potencia Max. (cv)		Dimensiones (AlxAnxProf.)	Corriente (A)	Contactor	Relé de sobrecarga		Fusible (A)
Carcasa NEMA	Carcasa IEC				RW	Rango (A)	
0,33	0,25	115x90x98	4	CW07	17D	2,8 - 4	10
--	0,5		6	CWB9	27D	4 - 6,3	10
--	0,75					5,6 - 8	20
0,75	1,0	185x105x111	8	CWB12	27D	8 - 12	25
1,0	1,5		12			10 - 15	35
1,5	2,0		16	CWB18	27D	15 - 23	50
2,0	3,0		23	CWB25	27D		
-	4,0						

Arranque Directo Trifásico DLW (Caja Termoplástica)

Código	Referencia	Potencia (cv)	Tamaño Caja
10074618	DLW-7D33P-R04	0,33 y 0,5	2
10074619	DLW-7D33P-R05	0,75	2
10074620	DLW-7D33P-R06	1 y 1,5	2
10074621	DLW-7D33P-R07	2	2
10074622	DLW-7D33P-R08	3	2
10074623	DLW-7D33P-R09	4	4
13338994	DLW-B9D33P-R63	5,5	4
13338984	DLW-B12D33P-R64	7,5	4
13338988	DLW-B18D33P-R66	10	4
13724880	DLW-B25D33P-R67	12,5	4
10074862	DLW-B25D33P-R68	15	4
13724998	DLW-B32D33P-R68	20	6



Dimensiones DLW

Potencia max. (cv)	Dimensiones (AlxAnxProf.)	In Max. (A)	Contactor CW/ CWB	Relé de Sobrecarga		Fusible (A)
				RW	Rango (A)	
0,33	115x90x98	1,2	07	17D	0,8 - 1,2	2
0,50		1,2	07	17D	0,8 - 1,2	4
0,75		1,8	07	17D	1,2 - 1,8	4
1,0		2,8	07	17D	1,8 - 2,8	6
1,5		4	07	17D	1,8 - 2,8	10
2,0		4	07	17D	2,8 - 4	10
3,0		6	07	17D	4 - 6,3	16
4,0	185x105x111	7	07	17D	5,6 - 8	20
5,5		9	9	27D	7 - 10	20
7,5		12	12	27D	8 - 12,5	35
10		17	18	27D	11 - 17	35
12,5		23	25	27D	15 - 23	50
15		23	25	27D	22 - 32	50
20		32	32	27D	25 - 40	63
25	210x120x126	45	50	67.1D	32 - 50	100
30	280x180x143	62	65	67.2D	40 - 57	100
40		62	65	67.2D	50 - 63	125